



EcoXCharge Clip

Carabiner Powerbank



Charges All USB Devices

Power Boost

The EcoXCharge Clip has a 3,350mAh battery to charge your smartphone and other USB devices for those situations when you need backup power.

Clip Almost Anywhere

EcoXCharge Clip can be attached to backpacks, tents and more.
Warning: Not for Climbing





Features

- Rugged & IPX7 Waterproof
- Shock resistant
- Built for rugged Australia & New Zealand Conditions
- Integrated Large Carabiner for easy carry
- Built in Rechargeable Lithium battery (3,350mAh)
- USB: 12" USB to Micro-USB
- Charge all USB devices, (5V 1.0A)

Input & Output

- Micro USB battery charging input jack
- USB Type-A device charge output jack

Size & Weight

Length	6.5cm
Width	2.3cm
Height	11.0cm
Weight	95g

MODEL GDI-EXCLP3351



9 355775 001136

* ECOXGEAR is covered by a 1 year limited warranty. To claim additional 2 years warranty, please register your product on our website ecoxgear.com.au